



## NX1P2-9024DT

Symac NX1P CPU with 24 Digital Transistor I/O (NPN), 1.5 MB memory, EtherCAT (0 servo axes, 4 PTP axes, 16 EtherCAT nodes), EtherNet/IP and 1 serial option port

# Specifications

Primary task cycle time	2 ms
Program memory	1.5 MB
Variables memory	2 MB
Max. number of synchronous axes	0
Max. number of PTP axes	4
Number of digital inputs	14
Input type	PNP/NPN
Number of digital outputs	10
Output type	NPN
Number of serial option boards	1
Max. number of expansion units	8
Max. number of remote I/O nodes	16
Communication port(s)	EtherCAT Master, EtherNet/IP, Ethernet TCP/IP
Number of Ethernet ports	2
Number of USB ports	0
Communication option(s)	Serial RS-232C, Serial RS-422, Serial RS-485
Real-time clock	✓
Supply voltage DC	20.4-28.8 V
Product Height (unpacked)	100 mm
Product Width (unpacked)	124 mm
Product Depth (unpacked)	71 mm
Product Weight (unpacked)	590 g



**CJ1W-BAT01**

Battery for CJ1M PLCs



**GX-JC03**

3-port EtherCAT Junction module, 24 VDC power supply



**GX-JC06**

6-port EtherCAT Junction module, 24 VDC power supply



**GX-JC06-H**

6-port EtherCAT Junction module, 24 VDC power supply, with node switches

**HMC-SD493**

SD memory card, 4 GB



**NX-PF0730**

NX I/O power feed unit, 5-24 V DC input, 8 terminals, 10A, screwless push-in connector, 12mm wide



**NX1W-ADB21**

Sysmac NX1P Analog I/O screwless option board, 2 x analog inputs 0 to 10 V, resolution 1/4000 or 0 to 20 mA, resolution 1:2000



**NX1W-CIF01**

Sysmac NX1P RS-232C screwless (15 m max.) serial communication option board



**NX1W-CIF11**

Sysmac NX1P RS422/485 screwless (50 m max.) serial communication option board



**NX1W-CIF12**

Sysmac NX1P RS422/485 screwless (isolated 500 m max.) serial communication option board



**NX1W-DAB21V**

Sysmac NX1P Analog I/O screwless option board, 2 x analog outputs 0 to 10 V, resolution 1:4000



**NX1W-MAB221**

Sysmac NX1P Analog I/O screwless option board, 2 x analog inputs 0 to 10 V, resolution 1:4000 or 0 to 20 mA, resolution 1:2000, 2 x analog outputs 0 to 10 V, resolution 1:4000



**SYSMAC-SE201L**

Sysmac Studio license. 1 Single user.



**W4S1-05D**

5-port enhanced Ethernet switch



**XS6W-6LSZH8SS200CM-B**

Ethernet patch cable, F/UTP, Cat.6A, LSZH (Blue), 2 m



**XS6W-6LSZH8SS500CM-Y**

Ethernet patch cable, F/UTP, Cat.6A, LSZH (Yellow), 5 m

## Spare parts

**NX-END02**

Spare part - End plate for NX1P controller

## Related products



### **NX I/O Series**

Performance and practicality  
for machine control

## Downloads

[CAD Library](#)



### EAC Mark removal Discontinuation Notice

EN PDF 221 KB



### NJ-series -[EtherCAT]- ORIENTAL MOTOR aSTEP DC Multi-Axis Drive (AZDxA-KED)

Connection Guide

EN PDF 3.99 MB



### NJ-series -[EtherNet/IP]- SMC AMS-S Series

Connection Guide

EN PDF 2.23 MB



### NJ-series -[Ethernet TCP/IP]- Hioki LCR Meter (IM3536)

Connection Guide

EN PDF 2.13 MB



### NJ/NX-Series CPU Unit Built-in EtherCAT Port

Users Manual

EN PDF 17.5 MB



### NJ/NX-Series CPU Unit Built-in EtherNet/IP Port

Users Manual

EN PDF 19.3 MB



### NJ/NX-Series CPU Unit Motion Control

Users Manual

EN PDF 19.8 MB



### NJ/NX-Series CPU Unit Software

Users Manual

EN PDF 24.2 MB



### NJ/NX-Series Instructions

Reference Manual

EN PDF 11.6 MB



### NJ/NX-Series Motion Control Instructions

Reference Manual

EN PDF 7.13 MB



### NJ/NX-Series Troubleshooting Manual

Users Manual

EN PDF 17 MB



### NJ/NX-Series for Motion Control

Getting Started Guide

EN PDF 18.1 MB



### NJ/NX-series - [EtherCAT]- CKD ABSODEX driver (AX9000TS/TH-U5)

Connection Guide

EN PDF 1.73 MB



### NJ/NX-series - [EtherCAT]- Denso Wave RC9 Robot

Connection Guide

EN PDF 2.72 MB



### NJ/NX-series - [EtherCAT]- Festo CPX- AP-I

Connection Guide

EN PDF 1.37 MB



### NJ/NX-series - [EtherCAT]- Festo MSE6-E2M

Connection Guide


EN PDF 1.6 MB



### NJ/NX-series - [EtherCAT]- HMS Anybus X-gateway ABX

Connection Guide

EN PDF 1.96 MB



### NJ/NX-series - [EtherCAT]- Hitachi ADV-Series AC Servo Drives

Connection Guide

EN ZIP 4.29 MB



### NJ/NX-series - [EtherCAT]- Inficon gauge (BPG402-SE)

Connection Guide

EN PDF 1.22 MB



### NJ/NX-series - [EtherCAT]- Kashiyama Dry Vacuum Pump (E- CAT01 1ch)

Connection Guide

EN PDF 1.59 MB



### NJ/NX-series - [EtherCAT]- Kashiyama Dry Vacuum Pump (E- CAT02)

Connection Guide

EN PDF 1.61 MB



### NJ/NX-series - [EtherCAT]- Kawasaki F- series Robot Controller F60

Connection Guide

EN PDF 2.32 MB



### NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]- CKD Sensor (PPX series)

Connection Guide

EN PDF 2.43 MB



### NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]- CKD Sensor (WFC series)

Connection Guide

EN PDF 2.75 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
CKD WFK2 Flow sensor**  
Connection Guide

EN PDF 2.09 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
MTS Sensors (E-Series)**  
Connection Guide

EN PDF 2.4 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
PATLITE Beacon (NE-IL)**  
Connection Guide

EN PDF 2.02 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
PATLITE Tower (LR6-IL)**  
Connection Guide

EN PDF 2.08 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
SMC (ISA3-xxx)**  
Connection Guide

EN PDF 2.61 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
SMC (xSE20Bx-L(-M/-P)-  
x)**  
Connection Guide

EN PDF 2.13 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
SMC ITVx000-IO\***  
Connection Guide

EN PDF 1.89 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
SMC Servo 24VDC  
(JXCL1)**  
Connection Guide

EN PDF 2.23 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
Schmalz Ejector (SCPSi)**  
Connection Guide

EN PDF 2.4 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
ifm (O5D10x/O5D15x)**  
Connection Guide

EN PDF 2.42 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
ifm (PN7x94)**  
Connection Guide

EN PDF 2.72 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
ifm (TN24xx)**  
Connection Guide

EN PDF 2.74 MB



**NJ/NX-series -  
[EtherCAT]- NX-ECC +  
NX-ILM400 -[IO-Link]-  
ifm TR7439 Pt100/1000**  
Connection Guide

EN PDF 2.43 MB



**NJ/NX-series -  
[EtherCAT]- Nidec  
Sanyo S-FLAG II Series  
AC Servo (DB6xx41)**  
Connection Guide

EN PDF 2.65 MB



**NJ/NX-series -  
[EtherCAT]- NittoSeiko  
SD600T driver controller**  
Connection Guide

EN PDF 2.18 MB



**NJ/NX-series -  
[EtherCAT]- ORIENTAL  
MOTOR Stepper Motor  
(AZ-series)**  
Connection Guide

EN PDF 2.89 MB



**NJ/NX-series -  
[EtherCAT]- Oriental  
Motor Alpha STEP AZ  
series**  
Connection Guide

EN PDF 3.47 MB



**NJ/NX-series -  
[EtherCAT]- SANYO  
DENKI AC Servo  
SANMOTION R 3E  
MODEL TYPE S**  
Connection Guide

EN PDF 3.08 MB



**NJ/NX-series -  
[EtherCAT]- SANYO  
DENKI AC Servo  
SANMOTION R  
ADVANCED MODEL  
TYPE F**  
Connection Guide

EN PDF 3.61 MB



**NJ/NX-series -  
[EtherCAT]- SHIMADZU  
Power Unit for Turbo  
Molecular Pump (TMP)**  
Connection Guide

EN PDF 1.29 MB



**NJ/NX-series -  
[EtherCAT]- SICK  
Absolute Encoder  
(AFS60/AFM60)**  
Connection Guide

EN PDF 1.52 MB



**NJ/NX-series -  
[EtherCAT]- Schmalz  
Compact Terminal  
(SCTSi-ECT)**  
Connection Guide

EN PDF 1.33 MB



**NJ/NX-series -  
[EtherCAT]- Unipulse  
Weighing Indicator  
(FC400-ECT)**  
Connection Guide

EN PDF 1.72 MB



**NJ/NX-series -  
[EtherCAT]- Weidmüller  
Remote I/O System (u-  
remote IP20)**  
Connection Guide

EN PDF 1.8 MB



### NJ/NX-series - [EtherCAT]- YASKAWA Sigma 7-series

Connection Guide

EN ZIP 3.77 MB



### NJ/NX-series -[EtherNet TCP/IP]- HIOKI Battery HiTESTER (BT356)[A]

Connection Guide

EN PDF 2.27 MB



### NJ/NX-series - [EtherNet/IP]- Balluff BNI EIP-50x-105-Z015

Connection Guide

EN PDF 3.35 MB



### NJ/NX-series - [EtherNet/IP]- CKD ABSODEX Driver (AX9000TS/TH-U6)

Connection Guide

EN PDF 1.71 MB



### NJ/NX-series - [EtherNet/IP]- HMS Anybus Communicator

Connection Guide

EN PDF 1.51 MB



### NJ/NX-series - [EtherNet/IP]- HMS Anybus X-gateway

Connection Guide

EN PDF 1.79 MB



### NJ/NX-series - [EtherNet/IP]- Hilscher netTAP NT100 Gateway (NT 100-RE-DN)

Connection Guide

EN PDF 3.5 MB



### NJ/NX-series - [EtherNet/IP]- IAI RCON system & MCON / MCON / MSEP Controller

Connection Guide

EN PDF 1.9 MB



### NJ/NX-series - [EtherNet/IP]- KOGANEI Manifold Solenoid Valve (F Series)

Connection Guide

EN PDF 2.43 MB



### NJ/NX-series - [EtherNet/IP]- Magnescale Digital Gauge (MG80-EI)

Connection Guide

EN PDF 1.84 MB



### NJ/NX-series - [EtherNet/IP]- Nordson ProBlue Adhesive Melters

Connection Guide

EN PDF 2.61 MB



### NJ/NX-series - [EtherNet/IP]- ORIENTAL MOTOR Alpha STEP Compatible Driver (AZD-xEP)

Connection Guide

EN PDF 1.82 MB



### NJ/NX-series - [EtherNet/IP]- SMC Solenoid Valve (SI Unit EX260-SEN#)

Connection Guide

EN PDF 1.65 MB



### NJ/NX-series - [EtherNet/IP]- Schmalz K.K. Compact Terminal (SCTSi-EIP)

Connection Guide

EN PDF 1.69 MB



### NJ/NX-series - [EtherNet/IP]- Unipulse FC400-EIP

Connection Guide

EN PDF 2.26 MB



### NJ/NX-series - [EtherNet/IP]- Unipulse FS2000-EIP

Connection Guide

EN PDF 3.38 MB



### NJ/NX-series - [EtherNet/IP]- ifm IO-Link master (AL1322)

Connection Guide

EN PDF 3.18 MB



### NJ/NX-series - [EtherNet/IP]- ifm IO-Link master (AL1920)

Connection Guide

EN PDF 3.07 MB



### NX-series -[Ethernet TCP/IP]- V330-F, V430-F Code Readers

Connection Guide

EN PDF 2.89 MB



### NX-series -[RS-232C]- V320-F, V420-F, V430-F Code Readers

Connection Guide

EN PDF 2.48 MB



### NX-series NX1P2 CPU Unit Built-in I/O and Option Board

Users Manual

EN PDF 6.4 MB



### NX-series NX1P2 CPU Unit Hardware

Users Manual

EN PDF 7.26 MB



### NX1-series + NX-ILM400 -[IO-Link]- SMC D-MP# Actuator Position Sensor

Connection Guide

EN PDF 1.88 MB



### NX1-series + NX-ILM400 -[IO-Link]- SMC Digital Flow Switch

Connection Guide

EN PDF 2.58 MB



**NX1P Machine Automation Controller**  
**Brochure**

EN PDF 1.77 MB



**NX1P Machine Automation Controller**  
**Datasheet**

EN PDF 4.31 MB



**NX1P-L**  
**Brochure**

EN PDF 14.7 MB



**NX1P-Series Machine Controller**  
**Datasheet**

EN PDF 1.7 MB



**NX1P2/NX1W-Series**  
**Instruction Sheet**

EN PDF 635 KB



**OEN Sample and Library files**  
**Connection Guide**

EN ZIP 9.25 MB



**Omron GX-JC0x-x**  
**EtherCAT Junction Box**  
**EtherCAT ESI file**

EN ZIP 3.36 KB




**Panel Building**  
**Brochure**

EN PDF 3.11 MB



**SYSMAC-XR020 MQTT**  
**Communications Library**  
**Flyer**

EN PDF 621 KB



**Sysmac**  
**Catalogue**

EN PDF 43.5 MB



**Sysmac: A Fully Integrated Platform**  
**Brochure**

EN PDF 11.8 MB